

EXTRACTOR INSTRUCTION MANUALS

**PLEASE USE THE DOWNDRAFT EXTRACTOR WHEN COOKING ON HOB
TO REDUCE ODOURS /CONDENSATION**

To operate extractor

Press + button and extractor will rise up and start on low speed.

Once it has reached full height, you can increase the extraction rate by pressing the + button up to maximum level 4.

To switch extractor off, press button to far left of control panel. Extractor will descend and motor will switch off.